



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 2000-2002
Make: Toyota
Model: Celica

INSTALLATION INSTRUCTIONS



What's in the Box: (2) Mesh Grill Pieces, (8) Ties, (1) Small Spool of Metal Wire (optional).

Tool List: Wire Cutters, 3M Foam Tape

Upper Bumper Mesh Installation:

1. Start by opening your hood and propping your hood up. You need to remove the factory emblem and gain access to behind the grill area.
2. Place the insert in the grill opening.
3. Holding the grill mesh in place, run ties through the stock emblem opening (starting them from behind the emblem opening) and the new grill. Then loop the cable tie back through an adjacent mesh diamond. Check to make sure the cable tie is going around one of the existing grill bars. The metal wire can be used an alternative for the ties if desired.
4. Clip the ends of the cable ties off.
5. To conceal any remaining parts of the cable tie on top of the mesh, it's possible to use a silver marker and brush over the tie in the areas where the mesh should be.

Lower Bumper Mesh Installation:

This can be installed without bumper removal. Follow the general guidelines in the video here on how to install the lower bumper mesh: http://www.youtube.com/watch?v=C_Km113J8I. Using some adhesive such as Automotive Goop or Silicone RTV may be advisable to hold the top flap in place as well

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .