



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 2001-2002
Make: Saturn
Model: SC

INSTALLATION INSTRUCTIONS



What's in the Box: (1) Grill Mesh Piece.



Tool List: Small Needle Nose Pliers, 10mm Socket with Ratchet and Extension

Mesh Installation:



1. Start by removing the stock plastic guard from the grill area.
 - a. Remove the 10mm nuts from the area where indicated with **green arrows**. The side nuts will need to be removed from underneath.
 - b. Remove the push screws from the area where indicated with **green circles** (located under the car)
 - c. Slide the plastic guard piece out from behind and set aside.
2. Slide the grill mesh in from behind and center it into position.
3. Reinstall the plastic guard piece in the reverse of the removal. The center nut will need to be reinstalled from behind.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com.