



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 1995-1996
Make: Saturn
Model: SC2

INSTALLATION INSTRUCTIONS



What's in the Box: (1) Grill Mesh Piece.



Tool List: N/A

Mesh Installation:



Clip Location

1. Take the grill insert and make sure you understand how it is supposed to go on. The top part has the clips but the insert should be pointing in a fashion of which the clips will attach to the bumper from behind.
2. Put the grill insert through the left side of the opening and feed it in as far as you can. Push the right part in and slide it over behind the painted part and in front of the black plastic.
3. Slide the insert over to the right and tuck the left portion in like you did on the opposite side. Center it and clip in by reaching your hand under the car and pushing the clips in from behind.
4. The clips should be near the arrows on the above picture.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .