



INSTRUCTIONS

Materials needed: Metal wire
Wire Cutters

Estimated Install time: 30 minutes

1. Cut 2-4 pieces of wire into 6" sections.
2. Pop the hood and place the inserts over the stock grill.
3. Then feed the wire through 2 holes next to each other so the ends are behind the grill and twist once for a temporary hold.
4. Repeat this step around the grill. Try to keep them in the corners and middle for the most secure hold.
5. Repeat step 4 until you have all the wire ends through the insert.
6. Twist the wire tight up against the insert using your pliers.
7. Clip the ends of the wire about 3 winds up with your wire cutters and bend the ends into the mesh.

NOTE: Some customers have experienced better install results by installing the mesh from behind. This is accomplished by removing the stock grill that is held in by clips and then placing the mesh on the stock grill. Then reinstall the grills with clips.