



## INSTRUCTIONS

Materials needed: Metal wire  
Wire Cutters

Estimated Install time: 30 minutes

1. Cut 2-4 pieces of wire into 6-9" sections.
2. Bent the wire so that it is in a "J" shape so that one end is longer than the other.
3. Place the new grills on top of the existing grills
4. Hold onto the long end of the wire and feed the bent portion of the wire through the grill and through a grill hole behind it.
5. Pull the wire back towards you so that the wire ends are in holes/diamonds next to each and twist once for a temporary hold.
6. Repeat this step around the grill. Try to keep them in the corners and middle for the most secure hold.
7. Repeat step 4-5 until you have all the wire ends through the insert.
8. Twist the wire tight up against the insert using your pliers.
9. Clip the ends of the wire about 3 winds up with your wire cutters and bend the ends into the mesh.

PLEASE NOTE: The instructions provided are suggested instructions. If you feel that the installation is inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. These instructions were designed for grill use in off-road use areas. If you have any suggestions on how to improve our installation instructions then please email your comments to [info@customcargrills.com](mailto:info@customcargrills.com)