



INSTRUCTIONS



Materials needed: Grills (included)
Screws (optional)

Estimated Install time: 15 minutes or more

1. Start by opening your hood.
2. Pull back the plastic chrome so it makes it very easy to insert the mesh.



3. Repeat for the top part of the grill.



4. To reensure the grill will stay in its place; a few screws can be mounted in the stock plastic grill.

