



## INSTRUCTIONS



Materials needed: Grills (provided)  
Cable Ties (provided)  
Wire Cutters

Estimated Install time: 30 minutes

1. Open the hood.
2. Loosen the top splash guard from the top of the grill area by releasing the 4 fastening mechanisms.
3. Place the lower insert in the lower grill opening.
4. Have someone hold the grill in. Run cable ties through the stock grill (starting them from behind the stock grill) and the new grill. Then loop the cable tie back through an adjacent mesh diamond. Check to make sure the cable tie is going around one of the existing grill bars
5. Secure the cable tie and repeat this process a few more times so that the grill is secured. We suggest a minimum of 2 cable ties on the left, center, and right sections.
6. Repeat step 3 & 4 for the upper section.
7. Clip the ends of the cable ties off
8. Replace the top splash guard, close hood, and enjoy.