



INSTRUCTIONS



Materials needed: Wire Ties (supplied)

Estimated Install time: 30 minutes

1. Open and prop the hood
2. Place the bottom insert over the stock grill in the bottom section.
3. Then feed a wire tie through from behind.
 - a. Feed the wire tie from behind the stock grill. You should be able to reach down there from the space between the bumper and engine compartment.
 - b. Send the end of the cable tie through towards the front of the bumper.
 - c. Loop it back through the next adjacent diamond on the new and existing grill.
 - d. Lock the end of the cable tie to the head of the cable tie and secure in place.
4. Repeat step 3 around the grill. Try to keep them in the corners and middle for the most secure hold.
5. Repeat for the top grill section.
6. Close hood and enjoy.