



INSTRUCTIONS



Materials needed: Grill and Nuts (provided)

Estimated Install time: < 10 minutes

1. Slide grill under the bumper and up towards the grill opening.
2. Push the grill on.
 - a. With the mesh grills, there will be precut holes where grill can slide on to the stock posts
 - b. With the woven grills, there are no specific holes for the grill to slide on to the stock post. Try to leave 1 woven square on each side, all the way around the grill.
3. Take the supplied speed nuts and at an angle start installing them. These will create threads on the plastic post if you have the at a 20-30 degree angle. Use the nuts so that the center bow faces the grill.

Be careful. The speed nuts do have sharp ends. The speed nuts can cut the nub off the posts IF a thread is not started.