



INSTRUCTIONS



Suggested Additional Materials :
3M Red-back Double Side Sticky Foam Tape (NOT PROVIDED)
Low Adhesion Masking Tape (NOT PROVIDED)

Estimated Install time: 30 minutes

1. Place the center grill piece in the grill area. Make sure the fit is correct. It may be a little tight at first but this is normal.
2. When you are satisfied with the placement, use some low adhesion masking tape and outline the area where the grill is.
3. Remove the grill insert
4. Using the low adhesion tape as a guide, outline the grill area with the 3M Red-Back tape.
5. Remove the low adhesion tape.
6. Remove the red back from the foam tape
7. Push the grill insert back in until it contacts the foam tape.
8. Side piece installation instructions are not developed at this time.