



INSTRUCTIONS



Materials needed: Wire (provided)
Wire Cutters

Estimated Install time: 30 minutes

1. Place the new grill insert on top of the existing grill
2. Cut a small length of wire and bend the wire so that it is in a “J” shape.
3. Hold onto the long end of the wire and feed the short end (the bent part) of the wire tie through the grill and through a grill hole behind it.
4. Pull the wire tie back towards you so that the wire ends are in holes/diamonds next to each and loosely secure the tie. Loosely secure the tie. Make sure you have the tie looped around one mesh diamond and one plastic OEM horizontal plastic bar.
5. Repeat this step around the grill. Try to keep them in the corners and middle for the most secure hold.
6. Repeat step 2-5 until you have all the wire ends through the insert.
7. When you are satisfied with the placement of the grill and the ties, fully tighten the ties.
8. Clip the ends of the ties.

ALTERNATE INSTALL: If you can gain access to behind the stock grill from under the car, you can conceal the “head” of the cable tie for a much better looking installation.

PLEASE NOTE: The instructions provided are suggested instructions. If you feel that the installation is inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. These instructions were designed for grill use in off-road use areas. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com