



## INSTRUCTIONS



Materials needed: Metal Wire (provided)  
Wire Cutters

Estimated Install time: 30 minutes

1. Cut 6-8 pieces of wire into 10" sections.
2. Place the new grill inserts into the existing grill openings.
3. Loop the wire through the grill so the ends are facing away from you.
4. Repeat this step around the grill. Try to keep them in the corners and middle for the most secure hold.
5. Repeat step 4 until you have all the wire ends are through the inserts.
6. Twist the wire tight up against the back supports and twist the ends tight.
7. Clip the ends of the wire about 3 winds up with your wire cutters and bend the ends into the mesh.