



INSTRUCTIONS



Materials needed: Grills

Estimated Install time: 10 Minutes

1. Read instructions before installation.
2. Take the grill insert and make sure you understand how it is supposed to go on. The top part has the clips but the insert should be pointing in a fashion of which the clips will attach to the bumper from behind.
3. Put the grill insert through the left side of the opening and feed it in as far as you can. Push the right part in and slide it over behind the painted part and in front of the black plastic.
4. Slide the insert over to the right and tuck the left portion in like you did on the opposite side. Center it and clip in by reaching your hand under the car and pushing the clips in from behind.
5. The clips should be near the arrows on the above picture.
6. Thanks and enjoy.