



INSTRUCTIONS



Materials needed: Metal Wire (provided)
Needle nose pliers
Wire Cutters
Phillips head screwdriver

Estimated Install time: 30 minutes

1. Take a Phillips head screwdriver and remove the 4 screws that hold the existing grill on. There are two in the front and two under the hood.
2. Take the existing grill off
3. Cut 2-4 pieces of wire into 4" sections.
4. Then place the insert grill over the existing grill.
5. Try to feed the wire through 2 holes next to each other and then twist the ends once from behind for a temporary hold.
6. Repeat step 3,4 & 5 until you have all the wire ends through the inserts.
7. Twist the wire tight up against the insert using your pliers.
8. Clip the ends of the wire about 3 winds up with your wire cutters and bend the ends into the mesh.
9. Reinstall grill in reverse order as you took it off.

Note: For the far left and right pieces can be notched out with wire cutters for the screws as shown above. This will make installation much easier. You can also leave the inserts as you received them and install them by running the wire from the back to the front. This is harder but will provide a better look when finished.