



INSTRUCTIONS



Materials needed: Wire Ties (provided)
Wire Cutters

Estimated Install time: 30 minutes

1. Start by holding the mesh grill over top of the existing grill. Determine which holes on the mesh to use that will wrap around the stock grill.
2. Run a wire tie through the grill and then around the OEM grill and back through an adjacent hole. Don't fully secure the ties until you have all in place. One in each corner is a suggested minimum amount of ties to use.
3. Secure the cable ties and trim the excess.

Alternate Installation Method:

Applying 3m red-back foam tape to the back of the grill that comes in contact with the stock grill is a good way to install the grill. This method is less secure than using cable ties.