



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 2004-2010
Make: Chevy
Model: Cobalt

INSTALLATION INSTRUCTIONS



What's in the Box: (2) Upper Bumper Mesh Grills, (8) Small Ties, (1) Spool of Wire

Tool List: Wire Cutters (to trim the install ties).

Upper Bumper Mesh Installation:

1. Start by opening the hood and propping the hood up.
2. Loosen the top part of the grill by removing the push rivets holding the splash guard on. This will gain you some extra room behind the grill for your arm to fit during the installation process.
3. Place the bottom mesh grill on top of the existing bottom grill grating.
4. Starting on one side, run a cable tie tail from the back of the existing grill and also through the mesh grill. The metal wire can be used an alternative to the ties.
5. Push the cable tie tail through an adjacent diamond (above or below) so that the cable tie will secure around one mesh diamond and on one stock grill horizontal bar.
6. Fasten the cable tie securely.
7. Repeat for the other side, and then apply some to the center areas.
8. Trim the cable tie ends if desired.
9. Repeat for the top grill.
10. Replace the push rivets, close the hood, and enjoy.
11. To conceal any remaining parts of the cable tie on top of the mesh, it's possible to use a silver marker and brush over the tie in the areas where the mesh should be.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .