



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 2007-2010
Make: Dodge
Model: Avenger

INSTALLATION INSTRUCTIONS



What's in the Box: (4,5,or 7) Mesh Grill Inserts, (16) Cable Ties.

Tool List: Drill with 3/16" Drill Bit, Wire Cutters.

Upper Bumper Grill Mesh Installation:

LOWER TWO INSERTS:

1. Open and prop your hood up. Remove the 6 push rivets that hold the factory grill on so that you can gain access to behind the factory grill. This will still be a tight fit for many people's hands as there isn't much clearance.
2. Place one of the inserts over the stock grill in the appropriate place.
3. Start to feed the cable ties in from behind. Push the "tail" part of the tie through first. The "head" part of the tie should be concealed behind the stock grill.
4. Loop the "tail" part of the tie through an adjacent vertical diamond in the mesh. When done properly, there should be a minimal amount of the tie shown on the front of the vehicle.
5. Loosely secure the tie. Make sure you have the tie looped around one mesh diamond and one plastic OEM horizontal plastic bar. Repeat this step around the grill. Try to keep the ties in the corners or middle for the most secure hold.
6. Repeat step 3-5 until you have a minimum of two of the tie ends through each insert.
7. When you are satisfied with the placement of the grill and the ties, fully tighten the ties.
8. Clip the ends of the ties.
9. Repeat steps 3-8 for the remainder of the inserts.

UPPER TWO INSERTS

10. Repeat the steps 2-9 for the upper grills but since the stock grill is solid in this area you will need to drill (2) 3/16" holes (where indicated with green circles) per cable tie.



Lower Bumper Grill Mesh Installation:

11. For the lower grill sections you will need to gain access to behind the openings from underneath the vehicle.
12. The center grill can be simply placed into position and tied on in the same manner as outlined in steps 2-9.
13. The outer pieces install the same way but you will need to drill (2) 3/16" holes (where indicated with green circles) per cable tie.



PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .