



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 2007-2012
Make: Dodge
Model: Caliber

INSTALLATION INSTRUCTIONS



What's in the Box: (4) Mesh Grill Pieces, (8) Ties, (1) Small Spool of Metal Wire (optional).

Tool List: Wire Cutters, Drill with 3/16" Drill Bit,

Upper Bumper Mesh Installation:

1. Test fit the pieces on the factory grill.
2. Start by opening your hood and propping your hood up. You need to remove the factory grill or gain access to behind the grill area.
3. Start with the top pieces. Since the stock grill is solid in this area you will need to drill (2) 3/16" holes (where indicated with green circles) per cable tie. Repeat the same method on bottom areas as well.



4. Run ties through the stock grill (starting them from behind the stock grill) and the new grill. Then loop the cable tie back through an adjacent mesh diamond. Check to make sure the cable tie is going around one of the existing grill bars. The metal wire can be used as an alternative for the ties if desired.
5. Repeat step 4 until the mesh inserts are fully secured by pulling the ties tight.
6. Clip the ends of the cable ties off.
7. Replace the grill or top splash guard, & close hood.
8. To conceal any remaining parts of the cable tie on top of the mesh, it's possible to use a silver marker and brush over the tie in the areas where the mesh should be.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com.