



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 1994-2001
Make: Dodge
Model: Ram

INSTALLATION INSTRUCTIONS



What's in the Box: (4) Mesh Grill Pieces, (8) Ties, (1) Small Spool of Metal Wire (optional).

Tool List: Wire Cutters

Upper Bumper Mesh Installation:

1. Gain access behind the stock grill or remove the factory grill shell.
2. Place one of the inserts over the stock grill in the appropriate place.
3. Start to feed the cable ties in from behind. Push the tail end of the tie through first. The head of the tie should be concealed behind the stock grill.
4. Loop the tail of the tie through an adjacent vertical diamond in the mesh. When done properly, there should be a minimal amount of the tie shown on the front of the vehicle.
5. Loosely secure the tie. Make sure you have the tie looped around one mesh diamond and one plastic OEM horizontal plastic bar.
6. Try to keep the ties in the corners and middle for the most secure hold.
7. Repeat step 3-5 until you have a minimum of two of the tie ends through each insert.
8. When you are satisfied with the placement of the grill and the ties, fully tighten the ties.
9. Clip the ends of the ties.
10. Repeat steps 4-8 for the remainder of the inserts.
11. To conceal any remaining parts of the cable tie on top of the mesh, it's possible to use a silver marker and brush over the tie in the areas where the mesh should be.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs.

customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .