



[www.customcargrills.com](http://www.customcargrills.com)  
[info@customcargrills.com](mailto:info@customcargrills.com)

customcargrills.com LLC  
PO Box 90004  
Grand Rapids, MI 49509  
(616) 889-2985

Year: 2003-2006  
Make: Hyundai  
Model: Tiburon

## INSTALLATION INSTRUCTIONS



**What's in the Box:** (1) Upper Mesh Grill, (8) Ties, (1) Small Spool of Metal Wire (optional).



**Tool List:** N/A

### Upper Bumper Mesh Installation:

1. Start by opening your hood and propping your hood up.
2. Remove the existing upper grill.
3. Put the grill in place – please note the location of the notch cutout for the hood latch release and install the grill so that you can release your hood in the future.



4. Starting from behind the grill, run wire ties through the old screw holes, through a grill hole and back around a vertically adjacent grill hole.

5. Repeat for all the old grill screw holes.



6. Cut the wire tie excess, close your hood and you are done.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to [info@customcargrills.com](mailto:info@customcargrills.com).