



www.customcargrills.com
info@customcargrills.com

customcargrills.com LLC
PO Box 90004
Grand Rapids, MI 49509
(616) 889-2985

Year: 1997-2003
Make: Pontiac
Model: Grand Prix GTP

INSTALLATION INSTRUCTIONS



What's in the Box: (4) Grill Mesh Pieces, (4) Screws.

Tool List: Phillips Screwdriver.

Mesh Installation:

1. Remove the stock top pieces by unscrewing the fasteners holding them in place.
2. Replace them with the new aluminum inserts. Use new screws to secure aluminum inserts in place or reuse the old screws if desired.
3. Start the installation on the bottom set by first removing the 3 push screws on each side. They are located at the top of each bottom section.

PLEASE NOTE! THE BOTTOM PIECES INSTALL FROM BEHIND! DO NOT INSTALL THEM FROM THE FRONT!

4. The 90 degree bent part of the grill will slide forward (from behind) and needs to be placed above the painted part of the lower section. This will sandwich it above the painted part and below the unpainted part.



5. Push the insert forward until the holes located with the holes are lined up with the stock holes where the push screws were.



6. Once the insert is lined up, replace the push screws.



Note: Some Grand Prix models have a splash guard under the bottom openings. The splash guard will need to be removed in order to gain access behind the opening.

PLEASE NOTE: The instructions provided are the suggested installation method. If you feel that the installation instructions are inadequate or unsafe then please feel free to develop your own installation techniques that fit your exact needs. customcargrills.com llc is not liable for any personal or property damage resulting from our products. If you have any suggestions on how to improve our installation instructions then please email your comments to info@customcargrills.com .