



Tools:

Socket Wrench

5/16 in. socket

10 mm. socket

Socket extensions

Phillips screwdriver

Torx T25

1. Remove 5 screws under the front bumper lip (5/16th)
2. Remove 3 screws holding the top of the front bumper closest to you (5/16th)
3.
 - a. Remove headlight assembly (2 5/16th screws on each light).
 - b. Unplug headlight and turn signal bulbs. To remove lights completely, it is necessary to pull on the front fascia to allow room for the headlight to be removed. Don't worry, the piece is very flexible.
4. Unplug fog light bulbs.
5. Unplug corner light bulbs.
6. Remove bolts from inside of fender wall which connect front bumper to quarter panels. There are 3 bolts on each side, 10mm.
7. Remove 2 bolts from each side on outside of fender in wheel well, Torx T25. It's easier to gain access if the wheel is turned.
8. Remove front bumper.
9. To change grills, there are 6 Phillips screws on each grill. Remove all bolts and replace old grill with new one.
10. Replace all 6 screws. When doing this, it's advisable to slowly tighten each bolt to allow for the metal to form to the fascia.
11. Replace front bumper on car. Be sure that the black piece of the wheel well liner is on the inside of the nose.
12. Put the 3 bolts back on each side on the inside fender wall. When doing this, pay attention to the alignment of the nose with the body of the car.
13. Replace T25 bolts on outside of wheel well.
14. Plug in fog light and corner light bulbs.
15. Reinstall headlights and plug in headlight and turn signal bulbs.
16. Replace three screws in front of the nose.
17. Replace 5 screws under the front lip.